

Getting started

EN



Erste Schritte

DE

Installation

This product does not require installation of any special drivers (Plug&Play). Standard operating system drivers USB/HID are used.

Usage / Configuration:

The SIK 2500 offers similar handling like any standard keyboard. Special functions are accessed by key combination with **Fn**. All keys are pre-configured with default codes. They can be adapted to customer's needs using our WinProgrammer software at any time.

KeyClick:

By default an acoustic feedback tone is output for each key press. You can alter the volume in several steps (Off ... Max):

Decrease Volume: **Fn** + **←** Increase Volume: **Fn** + **→**

Dimming the Backlight:

Intensity of the LED backlight can be altered in several levels (Off...Max):

Decrease backlight: **Fn** + **↓** Increase Backlight: **Fn** + **↑**

Cleaning:

The keys can be deactivated for cleaning – using macro {Keypad_Clean}. Please only use cleaning fluids without abrasive substances.

Cleaning mode: **Fn** + **F12** indicated by running LEDs

For additional help, please contact support@prehkeytec.de

Installation

Dieses Produkt benötigt keine speziellen Treiber (Plug&Play). Standard-Treiber des Betriebssystems für USB/HID werden verwendet.

Bedienung / Konfiguration:

Die SIK 2500 bietet ähnliche Bedienung wie übliche Standard-Tastaturen. Spezielle Funktionen erreicht man über Tastenkombination mit **Fn**. Alle Tasten sind mit Standardcodes vorbelegt, können aber mit unserer WinProgrammer Software jederzeit angepasst werden.

Akustische Rückmeldung: "KeyClick":

Bei jedem Tastendruck wird ein KeyClick als Rückmeldung ausgegeben. Die Lautstärke können Sie über folgende Tastenkombinationen anpassen:

KeyClick leiser: **Fn** + **←** KeyClick lauter: **Fn** + **→**

Dimmen der Hinterleuchtung:

Die Tastenbeleuchtung ist in mehreren Stufen einstellbar (Aus ... Max.):

Dunkler: **Fn** + **↓** Heller: **Fn** + **↑**

Reinigung:

Die Tastatur kann zum Reinigen abgeschaltet werden – über das Makro {Keypad_Clean}. Bitte nur Mittel ohne scheuernde Bestandteile verwenden.

Reinigungsmodus: **Fn** + **F12** angezeigt durch LED-Lauflicht

Weiterführende Hilfe erhalten Sie von support@prehkeytec.de

